

PRODUCT DESCRIPTION

A Novel, pure acrylic water based multi-substrate primer for use on a large range of house hold substrates under a range of Heritage water and solvent based Decorative products.

PRODUCT FEATURES

- Water Based/low odour can easily clean up the tools/application equipment with water with water
- Suitable for use on a wide range of house hold substrates
- Excellent adhesion on a wide range of clean house hold substrates
- Excellent, no mess application properties
- Economical-purchase one primer for a large range of painting requirements
- Suitable for interior and exterior use
- Can be over coated with a range of Heritage Paint's water and solvent based Decorative products

APPLICATION AREAS

- Degreased and/or Weathered Galvanised steel
- PVC gutters and down pipes
- Previously painted enamel surfaces
- Wood
- Ceramic tiles
- Melamine's/Formica®
- Cleaned degreased mild steel
- Dry concrete/cement plaster

SURFACE PREPARATION

General: All surfaces/substrates must be clean, dry, dust and Fungus/Algae free before painting. Light sanding of all substrates will improve product performance and is therefore highly recommended

Rusted Metal: Affected areas need to be cleaned back to bright metal by hand mechanical or blast cleaning

New Metal: Surfaces need to be abrasively degreased to remove the manufacturer's grease protective layer this process is repeated until the surface is water break free.

Wooden Surfaces (doors, window frames etc) Sand smooth, remove and discoloured wood

Ceramic tiles: Ensure tiles are clean, dry and dust free-Special care should be taken to clean/degrease tiles around kitchens and bathrooms with Prodec Aquaclenz degreaser. Then substrate must properly rinsed until water break free and then be allowed to dry. All grout must be repaired and sealed prior to painting **NB Prodec Super Primer is not for use on Floor tiles**

Previously Painted surfaces: remove all loose and flaking paint. Clean and degrease, then sand lightly with wet/dry sand paper to remove gloss. If the substrate is very friable/chalky then apply a thinned down coat of Heritage Bonding liquid before priming

Melamine/Formic® Dust/degrease and sand-not for areas with high traffic/wear only for areas such as kitchen, bathroom and bed room cupboards/frames etc

PVC Down pipes: Clean, degrease and lightly sand, rinse with water, allow to dry

Dry Brick/Plaster Remove all dust and loose grit-if the plaster/substrate is very powdery/friable Heritage Bonding liquid is a better option

APPLICATION PROCEDURE

- Brush or spray apply a generous coat of **Heritage Multi Substrate Primer** to the area, which needs protecting (for very severe cases e.g. in very harsh Marine environments 2 coats of Super Primer are required)
- Allow to dry over night before recoating with Heritage Paint's Solvent and Water Based products.

GENERAL

- Do not apply before 9am and after 4 pm in the Winter
- Do not apply exterior if it looks like rain will occur with in 4-6 hours of application
- This Product s ready for use un-thinned, thinning will reduce its hiding power and anti -corrosion protection imparted
- Although the spreading rate will vary with porosity and type of substrate
- For uncoated new work on 5-7 SQM/l for the first coat and 7-9 SQM/l for subsequent coats and for when applied to sealed, previously painted substrates
- Application equipment clean up is with Clean Water
- This Product should never be mixed with other products

COLOUR RANGE/QUANTITIES

- White only
- Available in 1/5/20lt

PRECAUTIONS

- This product is water based and meets the Latest EU requirements WRT VOC
- Not to be applied to Floor tiles
- Not to be applied to areas which receive prolonged water immersion e.g. showers



LEAVE A LASTING IMPRESSION



info@heritagepaints.co.za

www.heritagepaints.co.za | 0800 0 PAINT - 0800 0 72468

Heritage Paints C.C.18 Garland Street, Ophirton, Johannesburg