

PRODUCT DESCRIPTION

A Classical long oil alkyd based interior Flat Matt coating for those high traffic and Interior areas that need a highly washable coating.

PRODUCT FEATURES

- Highly washable, cleanable.
- Excellent adhesion to range of properly prepared substrates.
- Excellent, no mess application properties, with excellent, flow and levelling.
- High hiding power and film build .

APPLICATION AREAS

- Primed Plaster, Hardboard and Fibre cement walls.
- Primed metal and wooden substrates.

SURFACE PREPARATION

Rusted Metal: Affected areas need to be cleaned back to bright metal and spot primed with Heritage Water Based Metal primer.

New Metal: Surfaces need to be abrasively degreased (Heritage Galvanized Iron Cleaner) to remove the manufacturer's grease protective layer this process is repeated until the surface is water break free. After drying the whole substrate is coated with Heritage Water Based Metal Primer.

Uncoated concrete surfaces: Remove all dust, foreign material, Fungal, algae Growth. Fill and seal all visible cracks and coat with Heritage Plaster Primer

Uncoated weathered or new fibre cement surfaces: Remove dust, foreign material, Fungal, Algae growth and if friable, powdery seal with Heritage Plaster primer.

Raw Plaster: Remove all dust, foreign material, Fungal and Algae growth. Fill and seal all visible cracks and coat with Heritage Plaster Primer.

Previously Painted Surfaces: Remove all loose, flaking and bubbling paint. Remove all dust, grease, foreign material, Fungus and Algae growth. Allow to dry, if then powdery or friable seal with Heritage Plaster Primer. After drying over night all primed areas and previously areas must then be undercoated with Heritage Universal Undercoat.

APPLICATION PROCEDURE

- Stir well before use
- Brush or Mohair roller apply a generous coat of Heritage **Flat Matt Enamel** to the area, which needs protecting.
- Allow to dry 18-24hours before recoating.
- Brush, roller apply a second generous coat.
- Clean up application equipment with Mineral turpentine or Heritage Brush Cleaner/Degreaser.
- Only apply in ventilated areas, keep away from all ignition sources, flames and sparks. Do not eat drink or smoke while applying.

GENERAL

- Do not apply before 9am and after 4 pm in the Winter.
- Do not apply exterior if it looks like rain will occur within in 4-6 hours of application.
- Heritage **Flat Matt Enamel** is ready for use un-thinned, thinning will reduce its hiding power.
- Two coats of **Flat Matt Enamel** are used for best results.
- Although the spreading rate will vary with porosity and type of substrate. For uncoated new work on 7-9 SQM/l for the first coat and 10-12 SQM/l for subsequent coats and for when applied to sealed, previously painted substrates.
- Application equipment clean up is with Mineral turpentine/Heritage/Brush Cleaner Degreaser

COLOUR RANGE AND QUANTITIES

- Available in White and on the Heritage Tinting System.
- Available in 1, 5 and 20 Litres.

PRECAUTIONS

- This material is highly flammable and has a flashpoint of 37 deg C
- Use only in well ventilated areas and do not eat, drink or smoke during application.



LEAVE A LASTING IMPRESSION



info@heritagepaints.co.za

www.heritagepaints.co.za | 0800 0 PAINT - 0800 0 72468

Heritage Paints C.C. 18 Garland Street, Ophirton, Johannesburg