

# PVA ACRYLICS REPOTEX STIPPLE

# **PRODUCT DESCRIPTION**

New generation water based long life Exterior, Stipple Coating for those areas that need a highly durable Stipple Coating in a range of colours.

#### PRODUCT FEATURES

- Stipple Texture masks/hides plaster imperfections.
- Excellent adhesion.
- Excellent Flexibility-covers hair line cracks.
- · Good washability.
- · Good dirt shedding properties.
- Excellent, no mess application properties.
- · Low odour.
- If correctly applied to a properly prepared substrate the product has a life expectancy
  of 5-7 years, possibly longer.

### **APPLICATION AREAS**

- Plaster, Hardboard and Fibre cement walls.
- Primed metal and wooden substrates.

#### SURFACE PREPARATION

**Rusted Metal:** Affected areas need to be cleaned back to bright metal and spot primed with Heritage Water based Metal primer.

**New Metal:** Surfaces need to be abrasively degreased, with Heritage Galvanized Iron Cleaner to remove the manufacturer's grease protective layer this process is repeated until the surface is water break free. After drying the whole substrate is coated with Heritage Water Based Metal primer.

**Uncoated concrete surfaces:** Remove all dust, foreign material, Fungal, algae growth- fill and seal all visible cracks and coat with Heritage Plaster Primer.

**Uncoated weathered or new fibre cement surfaces:** Remove dust, foreign material, Fungal, Algae growth and if friable, powdery seal with Heritage Bonding liquid.

**Raw Plaster:** Remove all dust, foreign material, Fungal and Algae growth. Fill (with Crack or Repair Filler) and seal all visible cracks and coat with Heritage Plaster primer.

**Previously Painted Surfaces:** Remove all loose, flaking and bubbling paint. Remove all dust, foreign material, Fungus and Algae growth. Allow to dry, If then powdery or friable seal with Heritage bonding liquid or Plaster Primer.

# **APPLICATION PROCEDURE**

- Always stir well before use.
- Brush, roller or airless spray apply a generous coat of Heritage Repotex to the area, which needs protecting.
- Allow to dry 4-6 hours before recoating.
- Brush, roller or airless spray apply a second generous coat.

# **GENERAL**

- Do not apply before 9am and after 4 pm in the Winter.
- Heritage Texture Coat is ready for use un-thinned, thinning with water will reduce its hiding power.
- Two coats of Heritage Texture Cote are used for best results.
- Although the spreading rate will vary with porosity and type of substrate. For uncoated new work on 1-2SQM/I for the first coat and 2-3SQM/I for subsequent coats and for when applied to sealed, previously painted substrates.
- Application equipment clean up is with clean tap water.

# **COLOUR RANGE & QUANTITIES**

- Heritage Repotex is available in a range of popular ready mixed colours and on the Heritage Tinting system.
- Available in 1, 5 and 20 litres.

## **PRECAUTIONS**

- Heritage Repotex is not flammable.
- It contains no toxic substances.

